


# 9702 DW Cymbal Stand



# 9702 DW Cymbal Stand

Part Number	Description
DWSMQTH	5/16 X 3/4 QUICK TURN HANDLE
DWSM029	3/8" DRUM KEY SCREW (4 PACK)
DWSP352	CLAMP FOR LEG ASSEMBLY
DWSP353	8MM WING SCREW
DWSP364	PLASTIC BUSHING
DWSP422	1-1/8" STEEL WASHER
DWSP430	PLASTIC BUSHING THAT ACCEPTS 3/4" TUBE
DWSP431	TILTER ASSEMBLY
DWSP432	CYMBAL SEAT
DWSP481	1.25" HINGED TRIPOD MEMORY LOCK
DWSP488	PAIR OF TOP AND BOTTOM FELTS W/ WASHER
DWSP502	WASHER
DWSP503	3/4" RATCHET CASTING W/TUBE
DWSP504	3/4" RATCHET SPRING
DWSP506	3/4" RATCHET HOUSING
DWSP509	RATCHET BOLT WASHER
DWSP711	SET SCREW
DWSP728	WASHER
DWSP729	CLAMP SCREW FOR TUBE JOINT W/ SPRING
DWSP782	HINGE STYLE MEMORY FOR 1/2" ARM
DWSP730	CLAMP SCREW FOR TUBE JOINT, SHORT
DWSP917	DRUM KEY SCREW
DWSP2007	M8 WING NUT FOR TILTER (4 PACK)
DWSP2010	6MM WING NUT FOR TUBE JOINT (4 PACK)
DWSP2019	1" MEMORY LOCK
DWSP2020	3/4" MEMORY LOCK
DWSM2031	PUPPY BONE W/ ACCESSORY CYMBAL ARM
DWSP2080	BLACK PLASTIC CYMBAL SLEEVE

