




# 9999 DW Single Tom/Single Cymbal Stand



# 9999 DW Single Tom/Single Cymbal Stand

Part Number	Description
DWSMQTH	5/16 X 3/4 QUICK TURN HANDLE
DWSM029	3/8" DRUM KEY SCREW
DWSP118	CLAMP NUT LOCKWASHER
DWSP119	WINGNUT SPACER
DWSP129	CYMBAL ARM
DWSP341	RUBBER FOOT
DWSP352	CLAMP
DWSP353	8MM WING SCREW
DWSP364	PLASTIC BUSHING
DWSP422	1-1/8" STEEL WASHER
DWSP432	CYMBAL SEAT
DWSP435	SWING BLOCK
DWSP436	SPRING
DWSP457	1/2" TOM L-ARM (BALL-IN-SOCKET)
DWSP481	1.25" MEMORY LOCK
DWSM488	PAIR OF TOP AND BOTTOM FELTS W/ WASHER
DWSP502	WASHER
DWSP504	3/4" RATCHET SPRING
DWSP506	3/4" RATCHET HOUSING
DWSP509	RATCHET BOLT WASHER
DWSP728	WASHER
DWSP729	CLAMP SCREW
DWSP740	HEX NUT
DWSP741	8MM, WASHER
DWSP743	BOLT
DWSM782	1/2" MEMORY LOCK
DWSM798	DOG BONE ACCESSORY ARM
DWSM799	STR/BOOM CYM ARM W/DBL CLAMP - CLAMSHELL
DWSM912	1/2 X 18 BOOM CYMBAL ARM
DWSP917	DRUM KEY SCREW
DWSP990	BALL IN SOCKET ASSEMBLY WITH 1" TUBE
DWSP2007	M8 WING NUT FOR TILTER (4 PACK)
DWSP2019	1" MEMORY LOCK
DWSP2046	WING NUT, 2005 STYLE
DWSP2080	BLACK PLASTIC CYMBAL SLEEVE

